




by Honeywell


MLS Digital Luminaire Controllers
MLSM2000A - Control Module
DHW/DHS - Mini Detector Head
for use with Analogue 1-10V and Fixed-Output
Electronic High-frequency Ballasts



**Installation and Commissioning
Instructions**

Note: HP2000 required for commissioning

Electrical Connections



Mounting Details

The MLSM2000A Control Module is designed to be mounted within the luminaire on fixing centres of 135mm. Connections to the control module as shown above should be made using single-core wire (0.5-1.5mm²).

The interconnect cable between the detector head and the control module should be routed away from other luminaire internal wiring and away from the lamp end-caps.

The recommended position for the detector is in the middle of the luminaire. Where this is not possible and the detector is fitted near one end of the lamps, please ensure that the detector is at the 'cold' end of the lamps.

The DHW/S Mini Head should be mounted such that only the raised front section of the bezel protrudes through the cut out in the louvre or infill panel. This should be constructed in accordance with the dimensions above.

Installation Guidelines

1. The Mini Detector Head must be mounted within the luminaire. Do not mount remotely.
2. The connecting cable must not be extended.
3. Artificial light illuminating the Mini Detector Head must only be reflected from the room - i.e. there must be no direct illumination.
4. In order to achieve satisfactory light-level regulating operation, a detector must observe a substantially greater proportion of artificial light from the luminaire(s) under its control than from neighbouring luminaires not under its control. This is particularly important when planning the installed layout of linear luminaires that have an integral detector positioned at one end.

Commissioning

Detectors are supplied factory pre-set which ensures the lighting will switch on automatically as soon as power is applied. Final commissioning of the detectors requires the use of the HP2000 Programmer. Please refer to HP2000 instructions for comprehensive commissioning instructions.

Commissioning Detectors using the HP2000

1. Switch on HP2000 by pressing the red power button.
2. Point HP2000 at detector and press the DOWNLOAD button. The HP2000 will confirm the product's identity and call up the correct menu of parameters and their current settings.
3. Use a combination of UP, DOWN, FORWARD and BACK buttons to navigate the parameter menu, selecting options for each shown. (See Tips below.)
4. When options for all parameters have been selected, point the HP2000 at the detector and press the UPLOAD button. The luminaire(s) will switch off briefly during the programming process and the HP2000 shows DATA OK to confirm .
5. After a short period of inactivity (default 5 minutes), the HP2000 hibernates retaining the most recent settings.

Tips

- i) Where there are only two options such as ON/OFF, a double click of the OK button toggles between them.
- ii) Where there are multiple options, a double click of the OK button recalls a list of all options for that parameter. Use the UP, DOWN and OK buttons to select.
- iii) Use the OK button to go forward (through the menus) without displaying help pages.
- iv) Press UPLOAD at any time to transfer all current settings from the handset to the product.

Note: While commissioning can also be carried out using an HP10 Programmer, this method does not offer access to the full range of functions.

OneSwitch Dimming

OneSwitch dimming affords local control to the end-user whereby a simple, momentary, push-to-make wallswitch can be used to raise or lower the lighting level or to toggle the output ON/OFF. A press of less than 1 second will toggle the output status while a longer press will raise or lower the output. Each time the switch is pressed, the direction of dimming reverses. If the switch has not been pressed for 5 seconds, the direction will be up (brighter) - unless the output is already above 90% (dc 8V) in which case the direction is down. A wiring diagram is shown left.

Advanced Features

Photocell

The MLSM2000A incorporates a photocell which can be configured to operate in three different modes, selectable from within the product's menus on the HP2000 MLS Programmer. These modes are 'regulating', 'passive' and 'none'. Note that in *any* mode of operation, the photocell affects the light output only when the Entry Scene is set to Scene 1.

Setting the regulating photocell

The MLSM2000A is set by default to operate in 'regulating' mode. Using the HP2000 MLS Programmer, enter the Utilities menu and select 'Set Light Level'. Use the 'up' and 'down' buttons to manually adjust the light output from the luminaire(s) and when at the required level press and hold 'OK' to store. The luminaire(s) will blink to acknowledge a successful store operation.

Setting the passive photocell

Use Passive mode in applications where light level regulation is not required (eg, when controlling non-dimmable ballasts) but it is desirable to hold off the controlled lighting when natural light is sufficient.

The parameter '**Threshold**' on the HP2000 menu is used to programme the MLSM2000A's passive photocell set point, which determines whether the lights will be allowed to turn on as an unoccupied area is entered. The threshold is programmed as a number between 1 (darkest) and 254 (brightest). This number is not scaled to correlate with 'lux' measurements made using a light meter, but nevertheless is a true representation of the light level perceived by the MLSM2000A.

In order to assist with selection of the appropriate threshold setting, the light level currently perceived by the detector (in terms of a number between 1 and 254) can be viewed on the HP2000 screen briefly following a download operation. The number represents the light level immediately before the download operation took place. *Tip: turn the lights off first using the **User Remote** menu found in **Utilities** if you want to measure the perceived ambient light level with no contribution from the controlled lighting.*


Note: When setting the regulating light level as described in the previous section, the Threshold is also set to the current measured level.

Technical Data

MLS CABLE: 1.5mm² unscreened twisted-pair: see Application Note AN4001

MAXIMUM RECOMMENDED MOUNTING HEIGHT: 3.0m

RANGE: Cone-shaped detection pattern, diameter (at floor level) = 2.4 x mounting height



OPERATING VOLTAGE: 230V 50Hz (UK & Europe)

ta = 0 - 50°C

CAPACITY: **Total load must not exceed 2 AMPS, up to 4 Ballasts MAX**

Electronic, high-frequency ballasts ONLY

INTERCONNECT CABLE TEMPERATURE RATING: 60°C

COLOUR: White or silver bezel (DHW = White, DHS = Silver)

MATERIAL: UV stabilised polycarbonate (DHW/DHS)

Flame retardant PC/ABS (MLSM2000A)

IP RATING: 20

OVERALL DIMENSIONS: 32 (l) x 21.5 (w) x 21.3 (h) mm (DHW/DHS)

147.5 (l) x 30 (w) x 22 (h) mm (MLSM2000A)

WEIGHT: 32g (DHW/DHS)

48g (MSM2000A)

Important Additional Notes

1. A means for disconnection must be incorporated in the fixed wiring in accordance with the current wiring regulations.
2. The dimming control output should be connected only to the control input of the ballasts - never to other detectors.
3. This equipment should be used to control only those ballasts powered from the same phase as the detector.
4. Do not connect mains to the MLS bus.
5. It is imperative that the MLS bus is wired with the correct type of cable; normally it should be 1.5mm² unscreened twisted pair. Please read Application Note AN4001 for more details.
6. Due to the fact that the photocell is on the ceiling looking down, it is not possible for measurements made with a lux meter on the working plane to remain constant when daylight illuminates the ceiling and the working plane to a differing extent. Therefore, products of this type should be regarded as capable of maintaining an APPROXIMATE light level only.
7. This equipment switches lights no more frequently than would a responsible human occupant. However, manufacturers of some lighting types (e.g. '2D' luminaires) may specify a maximum number of switching cycles in order to achieve a predicted lamp life. Please check with the manufacturer of the luminaires to ensure that they are compatible with automatic controls in this respect.
8. Some devices in this product range feature a silvered surface finish; this is intended for decorative purposes only. Care should be taken to avoid accidental separation of the silvered coating from the product. If the unit is built into a luminaire that is subsequently wrapped in film having adhesive properties, it is recommended that a layer of suitable packaging material be used to protect the silvered area.

Ex-Or

Novar ED&S Limited
Haydock Lane, Haydock, Merseyside WA11 9UJ
Tel: +44 (0)1942 719229
Fax: +44 (0)1942 508753
Email: technicalsales.ex-or@honeywell.com
www.ex-or.com



At the end of their useful life the packaging and product should be disposed of via a suitable recycling centre. Do not dispose of with normal household waste. Do not burn.



W4205F